

substation - S60 - Sepam series 60

59787

Main

Main	
Relay application	Substation
Range of product	Sepam series 60
Device short name	S60
Control and monitoring type	Circuit breaker/contactor control ANSI code: 94/69 (option) Latching/acknowledgement ANSI code: 86 Logic discrimination ANSI code: 68 (option) Switching of groups of settings Annunciation ANSI code: 30 Automatic transfer (AT) (option) Logic equation editor 200 operators
Metering type	Positive sequence voltage Vd/rotation direction Frequency Calculated active and reactive energy (+/- W.h, +/- VAR.h) Active and reactive energy by pulse counting (+/- W.h, +/- VAR.h) (option) Phase current I1, I2, I3 RMS Demand current I1, I2, I3 Peak demand current IM1, IM2, IM3 Measured residual current I'0 Voltage U21, U32, U13, V1, V2, V3 Residual voltage V0 Negative sequence voltage Vi Active power P, P1, P2, P3 Reactive power Q, Q1, Q2, Q3 Apparent power S, S1, S2, S3 Peak demand power PM, QM Power factor Measured residual current I0, calculated I'0∑
Network and machine diagnosis type	Unbalance ratio/negative sequence current li Disturbance recording Tripping context Phase fault and earth fault trip counters Harmonic distortion (THD), current and voltage lthd, Uthd Difference in amplitude, frequency and phase of voltages with synchro-check option Cable arcing fault detection Phase displacement Datalog (DLG)
Switchgear diagnosis type	Cumulative breaking current CT/VT supervision ANSI code: 60FL Trip circuit supervision ANSI code: 74 (option) Nb of operations, operating time, charging time, nb of racking out operations (option)

Complementary

Complementary	
Type of measurement	Frequency Current Voltage Peak demand power Energy Power factor Harmonic distorsion (I THD & U THD) Power (P,Q)
Protection type	Recloser (4 cycles) ANSI code: 79 (option) Neutral voltage displacement ANSI code: 59N

Apr 17, 2023 Life Is On Schneider 1

Breaker failure ANSI code: 50BF Synchro-check ANSI code: 25 (option)

Earth fault/sensitive earth fault ANSI code: 50N/51N Earth fault/sensitive earth fault ANSI code: 50G/51G Negative sequence/unbalance ANSI code: 46

Overfrequency ANSI code: 81H Underfrequency ANSI code: 81L

Positive sequence undercurrent ANSI code: 27D Remanent undervoltage ANSI code: 27R Negative sequence overvoltage ANSI code: 47 Phase overcurrent ANSI code: 50/51 Undervoltage (L-L or L-N) ANSI code: 27 Rate of change of frequency ANSI code: 81R Overvoltage (L-L or L-N) ANSI code: 59

Communication port protocol Measurement readout (option): Modbus

Remote indication and time tagging of events (option): Modbus

Remote control orders (option): Modbus Remote protection setting (option): Modbus

Transfer of disturbance recording data (option): Modbus

Input output max capacity 28 inputs + 16 outputs

Communication compatibility IEC 61850

Modbus TCPIP Modbus RTU DNP3 IEC 60870-5-103

IEC 61850 goose message

User machine interface type Without

Without Remote Advanced Mimic-based

Packing Units

Unit Type of Package 1	PCE
Number of Units in Package 1	1
Package 1 Height	1.0 cm
Package 1 Width	1.0 cm
Package 1 Length	1.01 cm
Package 1 Weight	100.0 a

Recommended replacement(s)